

SET-UP SHEET

X1'24 SET-UP SHEET VER.1 ©XRAY

XRAY X1'24

RACE	Basic Set up / Foam - Carpet		
TRACK	Carpet		
NAME	XRAY	DATE	

QUAL POSITION	FINAL POSITION	BEST LAP TIME	LAPS	TIME
		/sec	/	

TRACK	
TRACK SURFACE	<input checked="" type="checkbox"/> CARPET <input type="checkbox"/> ASPHALT
TRACK LAYOUT	<input type="checkbox"/> TECHNICAL <input checked="" type="checkbox"/> MIXED <input type="checkbox"/> FAST
TRACTION	<input type="checkbox"/> LOW <input checked="" type="checkbox"/> MEDIUM <input type="checkbox"/> HIGH

CENTER SHOCK ABSORBER		
SPRING	OIL /cSt	REBOUND %
C2.3 - 2.6	600	0
PISTON	PISTON HOLES DIAMETER	FOAM INSERT
<input type="checkbox"/> 3 HOLES	<input checked="" type="checkbox"/> ø1.1mm	YES <input type="checkbox"/> NO <input checked="" type="checkbox"/>
<input checked="" type="checkbox"/> 4 HOLES	<input type="checkbox"/> ø1.2mm	
<input type="checkbox"/> PSS	<input type="checkbox"/> ø1.3mm	

DAMPING	
<input checked="" type="checkbox"/> SIDE TUBE	OIL 10K /cSt
<input type="checkbox"/> SIDE SHOCK	OIL /cSt

FRONT	TIRES	REAR
Contact	TIRES	Contact
HUDY	ADDITIVE	HUDY
15min	ADDITIVE TIMING	30min
10min	WIPE OFF TIME	10min
Timing: Temp.:	TIRES WARMER	Timing: Temp.:
FRONT LEFT FRONT RIGHT	ADDITIVE TREATED AREA	REAR LEFT REAR RIGHT

TRANSMISSION		
GEAR DIFF	SOLID AXLE	BALL DIFF
<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
OIL 5000 /cSt		LOOSE MEDIUM TIGHT

GEARING (spur) ÷ (pinion) = FDR		
SPUR GEAR /T	PINION /T	FINAL DRIVE RATIO
80T	34T	2.35

ELECTRONICS	
MOTOR	21.5T
SPEEDO	
SERVO	
BATTERIES	

BODY	
XRAY X1	

COMMENTS	
Gearing depends on Motor Brand and timing settings. This example is for the HW combo with 21.5T G4 and 50 degree timing. Super glue tire sidewall in front is needed. Wipe off the additive 10 mins before your run.	

